Compass Chair dimensions

User dimensions (inches)	R310 size 1	R320 size 2	R330 size 3	R340 size 4	R350 size 5
Height	36 – 43	43-48	48-55	55-63	63+
Knee to heel	9-11	101/2-121/2	121/2-141/2	141/2-161/2	161/2-181/2
Min-max thigh circumference for pelvic harness	101/2-231/2	12-281/2	14½-30½	15-34½	171/2-381/2



Key user dimension: height / knee to heel

The user's overall height and measurement from knee to heel is a general guide to help you select the appropriate chair. Choose the model that allows for growth.

Important: Make sure that seat width, depth and height are adequate for each user, and that the user's weight does not exceed the maximum working load.

Item dimensions (inches)	R310	R320	R330	R340	R350
Seat height	9,10,11	10½,11½,12½	121/2,131/2,141/2	14½,15½,16½	16½, 17½, 18½
Seat depth	91/2	11	12¾	14¾	161/2
Seat width	101/2	121/4	14	161/4	181⁄4
Backrest height	91/2	11	121/2	141⁄4	16
Armrest height above the seat	51/2	6	7	81⁄4	8¾
Armrest length	61/2	71/2	81/2	9¾	11
Max. working load (lb)	100	120	175	220	250

2024 order form



To order or get a quote:

Go online: https://www.rifton.com/compass-sizing

Email: sales@rifton.com
Call: 800.571.8198

Use dimension chart to select appropriate size.

	R310 size 1		R320 size 2		R330 size 3		R340 size 4		R350 size 5		
*Compass chair		R311	\$200 🗆	R321	\$ 230 🗌	R331	\$ 260 🗌	R341	\$290	R351	\$320 🗆
*Leg type	Standard	R314	\$150 🗌	R314	\$150 🗌	R314	\$150 🗌	R314	\$150	R314	\$150 🗌
	Stability (front and rear)	R316	\$175 🗌	R316	\$175 🗌						
	Standard with rear stability	R319	\$165 🗌	R319	\$165 🗌						
Seat belt		R312	\$47 🗌	R312	\$47 🗌	R332	\$47	R342	\$47 🗌	R342	\$47 🔲
Pelvic harness		R313	\$170 🗌	R323	\$180 🗌	R333	\$190 🗌	R343	\$200 🗆	R353	\$210 🗆
Low friction feet (Standard legs only)		R318	\$30 🗌	R318	\$30 🗆	R318	\$30 🗆	R318	\$30 🗌	R318	\$30 🗆

^{*} Required